

APC KEY 25

0x20	0x21	0x22	0x23	0x24	0x25	0x26	0x27
0x18	0x19	0x1A	0x1B	0x1C	0x1D	0x1E	0x1F
0x10	0x11	0x12	0x13	0x14	0x15	0x16	0x17
0x8	0x9	0xA	0xB	0xC	0xD	0xE	0xF
0x0	0x1	0x2	0x3	0x4	0x5	0x6	0x7

0x40	0x41	0x42	0x43	0x44	0x45	0x46	0x47
------	------	------	------	------	------	------	------

SCENE
LAUNCH

0x52

CLIP STOP

0x53

SOLD

0x54

REC. ARM

0x55

NOTE

0x56


SOFT STEPS

STOP
ALL CLIPS





AKAI
PROFESSIONAL

APC KEY 25



SCENE
LAUNCH



AKAI
PROFESSIONAL

